

Report Date: 2023/1/11

## 校正報告書

#### 校正暨量測實驗室-台中

Report No.: ETR2300906 第1百 共2頁 申請者 臺中榮民總醫院 Applicant 儀器名稱 溫度蒐集器 Equipment 製造廠商 **ESCORT** EI-IN-D-32-L 序號 1931-0074 Manufacturer Model Serial No. GENP-ET-T008(V 1.1) 校正程序 2023/1/6 收件日期 校正日期 2023/1/10 Procedure used Received Date Calibration Date 任學毅 校驗者 溫度℃ (23 ± 5) °C 相對濕度%  $(50 \pm 30) \%$ Operator Temperature Relative Humidity 顧客地址 臺中市407西屯區臺灣大道四段1650號 校正地點 實驗室 遊校地址 Location 實驗室使用標準器 / SGS Standards

製造廠商	機型	標準器校正日期
Manufacturer	Model	Calibration Date
Delta OHM	HD 2107.1/TP472I.0	2022/6/17
	Manufacturer	Manufacturer Model

RTD Temp & Humidity Chamber GIANT FORCE GTH-225-00-SP-AR 2022/4/8

序號	追溯單位	報告號碼	標準器有效日期
Serial Number	Traceability	Report No.	Due Date
22016310/20007791	SGS(TAF 0143)	ECR2221881	2023/6/16
MAA1404-005	SGS(TAF 0857)	EKR2204991	2023/4/7

- ◆ 台灣檢驗科技股份有限公司特此聲明本報告書內記載之標準器,依ILAC P10之規定,可追溯至ILAC MRA 國際實驗室認證聯盟相互承認協議成員 之認可實驗室,或各國家計量標準機構(NMI),或國際度量衡委員會相互認可協定之機構(CIPM MRA),或驗證參考物質(CRMs)。 有TAF認證標誌之報告表示符合全國認證基金會(TAF)認證範圍之校正項目證書;無TAF認證標誌之報告亦符合本實驗室標準校正作業程序及ISO/IEC 17025之規定。
- SGS Taiwan Ltd hereby declare that traceability follows ILAC P10(ILAC policy on the traceability of measurement results). All standards are directly traceable to TAF recognized lab (members of the ILAC MRA) or to National Metrology Institutes (NMI) or to other international standards (members of the CIPM MRA) or certified reference materials(CRMs). The report with "TAF" accredited symbol represents the certificate of calibration items conforming to TAF accreditation scope; Without "TAF" accredited symbol, the report also complies with the lab's standard
- calibration operating procedures and ISO/IEC 17025 requirements
- 本校正報告僅對上述儀器之校正項目有效且未經調整,報告內容不包含校正週期之建議以及符合性判定,除特別聲明外。
- The calibration report is only valid for the instrument mentioned above and has not been adjusted. Unless otherwise specified, the content of the report does not include the suggestion for calibration interval and the determination of compliance.
- 本校正報告部份複製及影本無效。
- To reproduce or copy calibration report in partial is not allowed.
- 校正程序名稱: 温濕度計(LOGGER)(實測比對法+遊校)校正作業程序
- Calibration SOP for Temperature-hygrometer (Logger) (Comparison method + on-site calibration)

This document is issued by the Company subject to its General Conditions of Service printed overleaf, available on request or accessible at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a> and, for electronic format documents, subject to Terms and Conditions for Electronic Documents at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a>. Attention is drawn to the limitation of liability, and within the limits of Client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction from the expressions and the remandation of the content or appearance of this document cannot be reproduced except in full, without prior written approval of the Company. Any unauthorized alteration, forgery or refer only to the sample(s) tested.

TWD 7031034



## 校正結果 (Calibration Results)



RptNo.: ETR2300906

第2頁 共2頁

温度部份:

器示值 (℃)	標準值 (℃)	器差值 (℃)
0.1	0.0	0.1
5.1	5.0	0.1
10.1	10.0	0.1

#### 校正說明:

- 1.器差值=器示值-標準值
- 2.器差%=【(器示值-標準值)÷標準值】\*100
- 3.器示值係指送校正件所顯示或設定之值
- 4.標準值係指工作標準件之輸出值或顯示值
- 5.校正能力係以約95%信賴水準, k=2之擴充不確定度表示
- 6. 擴充不確定度: 0.6 ℃
- 7.上述擴充不確定度已包含校正件之不確定度評估結果 -- THE END --



This document is issued by the Company subject to its General Conditions of Service printed overleaf, available on request or accessible at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a> and, for electronic format documents, subject to Terms and Conditions for Electronic Documents at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a>. Attention is drawn to the limitation of liability, indemnification and jurisdiction issues defined therein. Any holder of this document is advised that information contained hereon reflects the Company's findings at the immediate only and within the limits of Client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction for were: all their rights and obligations under the transaction documents. This document cannot be reproduced except in full, without prior written approval of the Company. Any unauthorized alteration, forgery or falsification of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law. Unless otherwise stated the results shown in this test report refer only to the sample(s) tested.

TWD 7031033



# 校正報告書

Report Date: 2023/1/11

校正暨量測實驗室-台中

		Report	No.: ETR2300907	第1頁	共2頁	
申請者			臺中榮民總醫院			
Applicant 儀器名稱						
Equipment						
製造廠商 Manufacturer	ESCORT	機型 Model	EI-IN-D-32-L	序號 Serial No.	1931-0084	
校正程序 Procedure used	GENP-ET-T008(V	1.1) 收件日期 Received	2023/1/6	校正日期 Calibration Date	2023/1/10	
校驗者 Operator	任學毅	溫度 ℃ Temperatur	(23 ± 5) ℃	相對濕度 % Relative Humidity	(50 ± 30) %	
顧客地址	臺	中市407西屯區臺灣		校正地點	實驗室	
遊校地址		安队宁は田士	西淮 罕 / CCC Ctondo	Location		
<b>基</b> 吳	名稱	具	票準器 / SGS Standa 機型		校正日期	
	uipment Wanufacturer		Model		权正日期 tion Date	
RTD THEI	ERMOMETER Delta OHM		HD 2107.1/TP472I.	0 2022	2022/6/17	
Temp & Humio	dity Chamber	GIANT FORCE	GTH-225-00-SP-AR	202	2/4/8	
序	號	追溯單位	報告號碼	標準器	有效日期	
Serial	Serial Number Traceability		Report No.	Due	Date	
22016310	/20007791	SGS(TAF 0143)	ECR2221881	2023	3/6/16	
MAA140	04-005	SGS(TAF 0857)	EKR2204991	202	3/4/7	

- ◆ 台灣檢驗科技股份有限公司特此聲明本報告書內記載之標準器,依ILAC P10之規定,可追溯至ILAC MRA 國際實驗室認證聯盟相互承認協議成員 之認可實驗室,或各國家計量標準機構(NMI),或國際度量衡委員會相互認可協定之機構(CIPM MRA),或驗證參考物質(CRMs)。 有TAF認證標誌之報告表示符合全國認證基金會(TAF)認證範圍之校正項目證書;無TAF認證標誌之報告亦符合本實驗室標準校正作業程序及ISO/IEC 17025之規定。
- SGS Taiwan Ltd hereby declare that traceability follows ILAC P10(ILAC policy on the traceability of measurement results). All standards are directly traceable to TAF recognized lab (members of the ILAC MRA) or to National Metrology Institutes (NMI) or to other international standards (members of the CIPM MRA) or certified reference materials(CRMs). The report with "TAF" accredited symbol represents the certificate of calibration items conforming to TAF accreditation scope; Without "TAF" accredited symbol, the report also complies with the lab's standard calibration operating procedures and ISO/IEC 17025 requirements.
- 本校正報告僅對上遞儀器之校正項目有效且未經調整,報告內容不包含校正週期之建議以及符合性判定,除特別聲明外。
- The calibration report is only valid for the instrument mentioned above and has not been adjusted. Unless otherwise specified, the content of the report does not include the suggestion for calibration interval and the determination of compliance.
- 本校正報告部份複製及影本無效。
- To reproduce or copy calibration report in partial is not allowed.
- 溫濕度計(LOGGER)(實測比對法+遊校)校正作業程序
- Calibration SOP for Temperature-hygrometer (Logger) (Comparison method + on-site calibration)

This document is issued by the Company subject to its General Conditions of Service printed overleaf, available on request or accessible at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a> and, for electronic format documents, subject to Terms and Conditions for Electronic Documents at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a>. Attention is drawn to the limitation of liability, and within the limits of Client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction from exercising all their rights and obligations under the transaction documents. This document cannot be reproduced except in full, without prior written approval of the Company. Any unauthorized alteration, forgery or felsification of the content or appearance of this document is unlawful and offenders may be prosecuted to the fullest extent of the law. Unless otherwise stated the results shown in this test root refer only to the sample(s) tested.



### 校正結果 (Calibration Results)



RptNo.: ETR2300907

第2頁 共2頁

温度部份:

器示值 (℃)	標準值 (℃)	器差值(℃)
0.2	0.0	0.2
5.1	5.0	0.1
10.1	10.0	0.1

#### 校正說明:

- 1.器差值=器示值-標準值
- 2.器差%=【(器示值-標準值)÷標準值】\*100
- 3.器示值係指送校正件所顯示或設定之值
- 4.標準值係指工作標準件之輸出值或顯示值
- 5.校正能力係以約95%信賴水準, k=2之擴充不確定度表示
- 6.擴充不確定度: 0.6 ℃
- 7.上述擴充不確定度已包含校正件之不確定度評估結果 -- THE END --



This document is issued by the Company subject to its General Conditions of Service printed overleaf, available on request or accessible at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a> and, for electronic format documents, subject to Terms and Conditions for Electronic Documents at <a href="http://www.sgs.com.tw/Terms-and-Conditions">http://www.sgs.com.tw/Terms-and-Conditions</a>. Attention is drawn to the limitation of liability, and within the limits of Client's instructions, if any. The Company's sole responsibility is to its Client and this document does not exonerate parties to a transaction from exercising all their rights and obligations under the transaction documents. This document cannot be reproduced except in full, without prior written approval of the Company. Any unauthorized alteration, forgery or refer only to the sample(s) tested.